

Schema Collegamento Pin

PONTI CONNETTORE X11

1-2 external e-stop A
3-4 operator safety A
5-6 acknowledge operator safety A
7-8 safe operational stop A
9-10 safety stop 2 A
11-12 external enabling 1 A
13-14 external enabling 2 A
19-20 external e-stop B
21-22 operator safety B
23-24 acknowledge operator safety A
25-26 safe operational stop B
27-28 safety stop 2 B
29-30 external enabling 1 B
31-32 external enabling 2 B

Revision #1

Created 2026-01-27 08:33:49 UTC by Tiziano

Updated 2026-01-27 08:34:11 UTC by Tiziano